



YOUR MAILBOX SHOULD BE INSTALLED ON A METAL OR WOODEN POST CEMENTED FIRMLY INTO THE GROUND. THE FRONT OF THE MAILBOX SHOULD BE ABOUT 12" BEHIND THE CURBLINE. THE HEIGHT OF THE MAILBOX SHOULD MEASURE APPROXIMATELY $3\frac{1}{2}'$ FROM THE GROUND TO THE BOTTOM OF THE MAILBOX.

